

Cautions

- Before installation, the pipe line must be cleaned of impurities
- In order to extend the service life of the solenoid valve, Y line filter should be installed in the front end of the solenoid valve.
- Please confirm the voltage, fluid, temperature and pressure before installation.
- DC voltage coil temperature rises due to long-time electrifying which would lead to decreased working ability; the less is recommended to electrify for long time.
- Before wiring or checking, be sure to turn the power off to avoid danger
- Please avoid facing up to the outlet hole when using the DIN plug coils, and indeed tighten it to prevent dust or rain water infiltration
- Non-explosion-proof products not cannot be installed in hazardous areas (Example: explosive gas) as well as perfect vacuum environment
- Water hammer may occur under certain pressure and the influence of the fluid, to avoid that, installing water hammer absorber is recommended.

Piping installation instruction

This product is not available for installing inversely or vertically, the pipe must be horizontal in order to avoid any mechanical problems.

